

LED Car Bulbs Reference Guide

The below bulb application guide shows how the bulb sizes are related. Most bulbs on the market have various names for the same bulb.

Below Type	Same as - Replaces Below Bulb Numbers
1157 (BAY15D)	1154 1493 2057 2357 2397 3496 1016 1034 1130 7528 7225
1156 (BA15S)	#93 1073 1093 1129 1141 1159 1295 1459 1619 1651 1680 3497 5007 5008 7506 7527
67	61 63 69 71 81 89 98 303 623 1003 1155 1247 1251 3497 5007 5008
BA9s	12MB 53 57 182 256 257 293 363 756 1445 1488 1813 1815 1889 1891 1892 1893 1895 1898
3157	3057 3155 3157 3357 3457 4057 4157 (not 3157-SRCK or SACK)*
3156	3056 3156 3356 3456 4156
194/168 Small Wedge	note: The following 194/168 type bulbs will replace any miniature wedge base bulb with a 3 digit part number 147 152 158 159 161 168 184 192 193 259 280 285 447 464 555 558 585 655 656 657 1250 1251 1252 2450 2652 2921 2825
921/ T13	
Same Base as 194/168 Just Larger	901 904 906 908 909 912 914 915 916 917 918 920 921 922 923 926 927 928 939
74	17 18 37 70 73 79 85 86
3022	3021 3175 DE3175 6423 6428 6430 6461
3610	6418
4410	211 212-2 214-2 6411 6413 6429 4411
RL4410	578

You must use 3157-SRCK (Red) bulbs, **NOT** 3157 bulbs, to replace:

- 1988-1999 (Old Body Style) Chevy and GMC full size trucks & SUVs center tail lamp bulbs
(Our 3157 bulbs can be used for top tail lamp bulbs)
- 1995-2001 Cavalier and Sunfire tail lamp bulbs
- 1992-1998 Grand Am tail lamp bulbs
- 2004-2007 Dodge Ram truck tail lamp bulbs

***Note**

Use Special 3157-SACK (Amber) bulbs, **NOT** 3157 bulbs, to replace:

- Toyota Tundra **front turn signals**

Order your replacement LED bulbs by visiting our [Car LED Bulbs Page](#)

HIDXenonLights.com